

## **Chapter 9:**

---

# **Circuit Switching and Packet Switching**

## **Switching Networks**


---

- Long distance transmission is typically done over a network of switched nodes
- Nodes not concerned with content of data
- End devices are stations
  - Computer, terminal, phone, etc.
- A collection of nodes and connections is a communications network
- Data is routed by being switched from node to node

## Nodes

- Nodes may connect to other nodes only, or to stations and other nodes
- Node to node links usually multiplexed
- Network is usually partially connected
  - Some redundant connections are desirable for reliability
- Two different switching technologies
  - Circuit switching
  - Packet switching

## Simple Switched Network



## **Circuit Switching**

---


- Dedicated communication path between two stations
- Three phases
  - Establish
  - Transfer
  - Disconnect
- Must have switching capacity and channel capacity to establish connection
- Must have intelligence to work out routing

## **Circuit Switching**

---

- Inefficient
  - Channel capacity dedicated for duration of connection
  - If no data, capacity wasted
- Set up (connection) takes time
- Once connected, transfer is transparent
- Developed for voice traffic (phone)


# Public Circuit Switched Network



# Telecom Components

- Subscriber
  - Devices attached to network
- Subscriber line
  - Local Loop
  - Subscriber loop
  - Connection to network
  - Few km up to few tens of km
- Exchange
  - Switching centers
  - End office - supports subscribers
- Trunks
  - Branches between exchanges
  - Multiplexed

## Circuit Establishment



CS42

ice 10

## Circuit Switching Concepts


- Digital Switch
  - Provide transparent signal path between devices
- Network Interface
- Control Unit
  - Establish connections
    - Generally on demand
    - Handle and acknowledge requests
    - Determine if destination is free
    - construct path
  - Maintain connection
  - Disconnect

CS420/520 Axel Krings

Page 10

Sequence 10

## Circuit Switch Elements



CS420/520 Axel Krings

Sequence 10

## Blocking or Non-blocking

- Blocking
  - A network is unable to connect stations because all paths are in use
  - A blocking network allows this
  - Used on voice systems
    - Short duration calls
- Non-blocking
  - Permits all stations to connect (in pairs) at once
  - Used for some data connections


CS420/520 Axel Krings

Page 12

Sequence 10

## Space Division Switch

---



CS420/520 Axel Krings

Output Lines

Sequence 10

## Space Division Switching

---

- Developed for analog environment
- Separate physical paths
- Crossbar switch
  - Number of cross-points grows in  $n^2$
  - Loss of cross-point prevents connection
  - Inefficient use of cross-points
    - All stations connected, only a few cross-points in use
  - Non-blocking

CS420/520 Axel Krings


Page 14

Sequence 10

## Multistage Switch

- Reduced number of cross-points
- More than one path through network
  - Increased reliability
- More complex control
- May be blocking


## Three Stage Space Division Switch





## Interconnection Networks

- Omega Network




## Interconnection Networks

- Butterflies

- isomorphic to Omega (a composition of shuffle-exchange networks with programmable switches) and SW-Banyan switch
- closely related to hypercube and shuffle-exchange network
- number of nodes  $N = (k + 1)2^k$ 
  - this means  $k + 1$  rows (or ranks) consisting of  $n = 2^k$  nodes each
- Let  $\text{node}(i,j)$  refer to the  $j$ -th node in the  $i$ -th row, where  $i$  is in  $[0,k]$
- Then  $\text{node}(i,j)$  in row  $i > 0$  is connected to two nodes in row  $i-1$ 
  - $\text{node}(i-1,j)$  and  $\text{node}(i-1,m)$  where  $m$  is the integer found by inverting the  $i$ -th most significant bit in the binary representation of  $j$ .
- Note that if  $\text{node}(i,j)$  is connected to  $\text{node}(i-1,m)$ , then  $\text{node}(i,m)$  is connected to  $\text{node}(i-1,j)$ .
- Benes network is consisting of two butterflies back to back

## Interconnection Networks

- Butterflies





## Time Division Switching

- Modern digital systems rely on intelligent control of space and time division elements
- Use digital time division techniques to set up and maintain virtual circuits
- Partition low speed bit stream into pieces that share higher speed stream

# Interconnection Networks


## An Application: ATM switch architecture



# Interconnection Networks

## —Delta Switch Matrix

- non-blocking/blocking
- self routing



## **Control Signaling Functions**

- Audible communication with subscriber
- Transmission of dialed number
- “Call cannot be completed” indication
- “Call ended” indication
- Signal to ring phone
- Billing info
- Equipment and trunk status info
- Diagnostic info
- Control of specialist equipment

## **Control Signal Sequence**

- Both phones on hook
- Subscriber lifts receiver (off hook)
- End office switch signaled
- Switch responds with dial tone
- Caller dials number
- If target not busy, send ringer signal to target subscriber
- Feedback to caller
  - Ringing tone, engaged (busy) tone, unobtainable
- Target accepts call by lifting receiver
- Switch terminates ringing signal and ringing tone
- Switch establishes connection
- Connection release when Source subscriber hangs up

## **Switch to Switch Signaling**

- Subscribers connected to different switches
- Originating switch seizes inter-switch trunk
- Send “off hook” signal on trunk, requesting digit register at target switch (for address)
- Terminating switch sends “off hook” followed by “on hook” (wink) to show register ready
- Originating switch sends address

## **Location of Signaling**

- Subscriber to network
  - Depends on subscriber device and switch
- Within network
  - Management of subscriber calls and network
  - more complex

## **In Channel Signaling**

- Use same channel for signaling and call
  - Requires no additional transmission facilities
- Inband
  - Uses same frequencies as voice signal
  - Can go anywhere a voice signal can
  - Impossible to set up a call on a faulty speech path
- Out of band
  - Voice signals do not use full 4kHz bandwidth
  - Narrow signal band within 4kHz used for control
  - Can be sent whether or not voice signals are present
  - Need extra electronics
  - Slower signal rate (narrow bandwidth)


## **Drawbacks of In Channel Signaling**

- Limited transfer rate
- Delay between entering address (dialing) and connection
- Overcome by use of common channel signaling


## Common Channel Signaling

- Control signals carried over paths independent of voice channel
  - One control signal channel can carry signals for multiple subscriber channels
    - Common control channel for these subscriber lines
  - Associated Mode
    - Common channel closely tracks inter-switch trunks
  - Disassociated Mode
    - Additional nodes (signal transfer points)
    - Effectively two separate networks

## Common v. In Channel Signaling




(a) Inchannel



(b) Common channel

CCIS SIG: Common-channel interoffice signaling equipment  
SIG: Per-trunk signaling equipment

## Common Channel Signaling Modes



CS420/520 Axel Krings

## Signaling System Number 7

- SS7 is an open-ended common channel signaling standard
- Common channel signaling scheme
  - Especially designed to be used in ISDN (Integrated Services Digital Network)
  - Optimized for 64kbps digital channel network
  - Call control, remote control, management and maintenance
  - Reliable means of transfer of info in sequence
  - Will operate over analog and below 64kbps
  - Point to point terrestrial and satellite links

CS420/520 Axel Krings

Page 32

Sequence 10




# SS7

## Signaling Network Elements

- Signaling point (SP)
  - Any point in the network capable of handling SS7 control message
- Signal transfer point (STP)
  - A signaling point capable of routing control messages
- Control plane
  - Responsible for establishing and managing connections
- Information plane
  - Once a connection is set up, info is transferred in the information plane

## Transfer Points



STP = Signaling transfer point  
SP = Signaling point  
TC = Transit center  
LE = Local Exchange


## **Signaling Network Structures**

- STP capacities determine
  - Number of signaling links that can be handled
  - Message transfer time
  - Throughput capacity
- Network performance affected by
  - Number of SPs
  - Signaling delays
- Availability and reliability
  - Ability of network to provide services in the face of STP failures

## **Softswitch Architecture**


- General purpose computer running software to make it a smart phone switch
- Lower costs
- Greater functionality
  - Packetizing of digitized voice data
  - Allowing voice over IP
- Most complex part of telephone network switch is software controlling call process
  - Call routing
  - Call processing logic
  - Typically running on proprietary processor
- Separate call processing from hardware function of switch
- Physical switching done by media gateway
- Call processing done by media gateway controller

# Traditional Circuit Switching



(a) Traditional circuit switching

# Softswitch



(b) Softswitch architecture


## **Packet Switching Principles**

- Circuit switching designed for voice
  - Resources dedicated to a particular call
  - Much of the time a data connection is idle
  - Data rate is fixed
    - Both ends must operate at the same rate

## **Packet Switching: Basic Operation**

- Data transmitted in small packets
  - Typically 1000 octets
  - Longer messages split into series of packets
  - Each packet contains a portion of user data plus some control info
- Control info
  - Routing (addressing) info
- Packets are received, stored briefly (buffered) and past on to the next node
  - Store and forward

## Use of Packets



## Advantages

- Line efficiency
  - Single node to node link can be shared by many packets over time
  - Packets queued and transmitted as fast as possible
- Data rate conversion
  - Each station connects to the local node at its own speed
  - Nodes buffer data if required to equalize rates
- Packets are accepted even when network is busy
  - Delivery may slow down
- Priorities can be used

## **Switching Technique**

---


- Station breaks long message into packets
- Packets sent one at a time to the network
- Packets handled in two ways
  - Datagram
  - Virtual circuit

## **Datagram**

---

- Each packet treated independently
- Packets can take any practical route
- Packets may arrive out of order
- Packets may go missing
- Up to receiver to re-order packets and recover from missing packets

## Datagram Diagram



CS420/520 Axel Krings

## Virtual Circuit


- Preplanned route established before any packets sent
- Call request and call accept packets establish connection (handshake)
- Each packet contains a **virtual circuit identifier** instead of destination address
- No routing decisions required for each packet
- Clear request to drop circuit
- Not a dedicated path

CS420/520 Axel Krings

Page 46

Sequence 10

## Virtual Circuit Diagram



CS420/520 Axel Krings

## Virtual Circuits vs. Datagram

- Virtual circuits
  - Network can provide sequencing and error control
  - Packets are forwarded more quickly
    - No routing decisions to make
  - Less reliable
    - Loss of a node loses all circuits through that node
- Datagram
  - No call setup phase
    - Better if few packets
  - More flexible
    - Routing can be used to avoid congested parts of the network


CS420/520 Axel Krings

Page 48

Sequence 10




# Packet Size



# Circuit vs Packet Switching

- Performance
  - Propagation delay
  - Transmission time
  - Node delay

# Event Timing



## X.25

- We will only briefly cover this as an overview

## **X.25**

---

- 1976
- Interface between host and packet switched network
- Almost universal on packet switched networks and packet switching in ISDN
- Defines three layers
  - Physical
  - Link
  - Packet

## **X.25 - Physical**

---

- Interface between attached station and link to node
- Data terminal equipment DTE (user equipment)
- Data circuit terminating equipment DCE (node)
- Uses physical layer specification X.21
- Reliable transfer across physical link
- Sequence of frames

## **X.25 - Link**

---


- Link Access Protocol Balanced (LAPB)
  - Subset of HDLC
  - see chapter 7

## **X.25 - Packet**

---

- External virtual circuits
- Logical connections (virtual circuits) between subscribers

## X.25 Use of Virtual Circuits



## Virtual Circuit Service

- Logical connection between two stations
  - External virtual circuit
- Specific preplanned route through network
  - Internal virtual circuit
- Typically one to one relationship between external and internal virtual circuits
- Can employ X.25 with datagram style network
- External virtual circuits require logical channel
  - All data considered part of stream


## **X.25 Levels**

---

- User data passes to X.25 level 3
- X.25 appends control information
  - Header
  - Identifies virtual circuit
  - Provides sequence numbers for flow and error control
- X.25 packet passed down to LAPB entity
  - recall LAPB = Link Access Procedure Balanced
- LAPB appends further control information

## **User Data and X.25 Protocol Control Information**

---



## **Frame Relay**

- Designed to be more efficient than X.25
- Developed before ATM
- Larger installed base than ATM
- ATM now of more interest on high speed networks

## **Frame Relay Background - X.25**

- Call control packets, in band signaling
- Multiplexing of virtual circuits at layer 3
- Layer 2 and 3 include flow and error control
- Considerable overhead
- Not appropriate for modern digital systems with high reliability

## **Frame Relay - Differences**

- Call control carried in separate logical connection
- Multiplexing and switching at layer 2
  - Eliminates one layer of processing
- No hop by hop error or flow control
- End to end flow and error control (if used) are done by higher layer
- Single user data frame sent from source to destination and ACK (from higher layer) sent back

## **Advantages and Disadvantages**

- Lost link by link error and flow control
  - Increased reliability makes this less of a problem
- Streamlined communications process
  - Lower delay
  - Higher throughput
- ITU-T recommend frame relay above 2Mbps



## Protocol Architecture




Figure 10.18 Frame Relay User-Network Interface Protocol Architecture

## Control Plane

- Between subscriber and network
- Separate logical channel used
  - Similar to common channel signaling for circuit switching services
- Data link layer
  - LAPD (Q.921)
  - Reliable data link control
  - Error and flow control
  - Between user (TE) and network (NT)
  - Used for exchange of Q.933 control signal messages

## **User Plane**

---

- End to end functionality
- Transfer of info between ends
- LAPF (Link Access Procedure for Frame Mode Bearer Services) Q.922
  - Frame delimiting, alignment and transparency
  - Frame mux and demux using addressing field
  - Ensure frame is integral number of octets (zero bit insertion/extraction)
  - Ensure frame is neither too long nor short
  - Detection of transmission errors
  - Congestion control functions

## **User Data Transfer**

---

- One frame type
  - User data
  - No control frame
- No inband signaling
- No sequence numbers
  - No flow nor error control

## **Summary**

---

- circuit verses packet switching network approaches
- X.25
- frame relay